

## 6.2 The location various driver source code

Description: Extract kernel source (linux-2.6.32.2.tgz compressed files) can be found in the following driver, mini2440 based linux-2.6.32.2 kernel can use the driver source code and absolutely library 100%, please rest assured to use.

- (1) DM9000 network card driver  
linux-2.6.32.2/drivers/net/dm9000.c
- (2) Serial port drivers (including three serial drivers 0, 1, 2 corresponding to the device name /dev/ttySAC0, SAC1, SAC2)  
linux-2.6.32.2/drivers/serial/s3c2440.c
- (3) RTC driver  
linux-2.6.32.2/drivers/rtc/rtc-s3c.c
- (4) LED drivers  
linux-2.6.32.2/drivers/char/mini2440\_leds.c
- (5) Button drivers  
linux-2.6.32.2/drivers/char/mini2440\_buttons.c
- (6) Touch Screen driver  
linux-2.6.32.2/drivers/input/touchscreen/s3c2410\_ts.c
- (7) yaffs2 file system source code directory  
linux-2.6.32.2/fs/yaffs2
- (8) USB mouse/keyboard source code  
linux-2.6.32.2/drivers/usb/hid
- (9) SD/MMC card driver source code directory (support maximum capacity high-speed 32GB SD card)  
linux-2.6.32.2/drivers/mmc
- (10) NAND Flash driver  
linux-2.6.32.2/drivers/mtd/nand

- (11) UDA1341 audio driver directory  
linux-2.6.32.2/sound/soc/s3c24xx
- (12) LCD driver  
linux-2.6.32.2/drivers/video/s3c2410fb.c
- (13) USB storage support driver  
linux-2.6.32.2/drivers/usb/storage
- (14) USB camera driver  
linux-2.6.32.2/drivers/media/video/gspca
- (15) I2C EEPROM driver  
linux-2.6.32.2/drivers/i2c
- (16) Backlight driver  
linux-2.6.32.2/drivers/video/mini2440\_backlight.c
- (17) PWM control buzzer driver  
linux-2.6.32.2/drivers/char/mini2440\_pwm.c
- (18) Watchdog driver  
linux-2.6.32.2/drivers/watchdog/s3c2410\_wdt.c
- (19) ADC (analog to digital converter) driver  
linux-2.6.32.2/drivers/char/mini2440\_ad.c
- (20) CMOS camera driver  
linux-2.6.32.2/drivers/media/video/s3c2440camif.c
- (21) USB Wireless LAN driver (Model: TL-WN321G+)  
linux-2.6.32.2/drivers/net/wireless/rt2x00
- (22) USB to Serial driver  
linux-2.6.32.2/drivers/usb/serial/pl2302.c